

EINBAUANLEITUNG CR

Einbauanleitung CR am Beispiel Hyundai Tucson 2.0 crdi



The box will be fitted between the pressure sensor from the common-rail and the original wiring loom.

You can then see in the 2 picture the detail from the pressure sensor.

Remove the connector and plug the PSI-connector on the pressuresensor.
2 Step is to connect the other side from the PSI-Box to the cars connector.

Fit the box in a secure place against water and vibrations.

Be carefull with the orientation from the male PSI-Connector to the cars female connector.
Don't crossover the orientation, because the BOX will be permanently damaged.

Remount the cover and the plug.

